

# Panasonic

## ASSEMBLY TOOLS



Accupulse



Precision Clutch



Mechanical Pulse



Assembly Qualifiers

Best Practices, Quick Guides,  
Warranty Instructions & Worksheets

**Best  
Practices!**









## **Guides, Instruction, Tool Certification Guide & Worksheets**

### Table of Contents

	Page Number
Identifying Joint Type.....	3
Remote Control Setup.....	4
Remote Programming Guides.....	5-7
Setup Work Sheet.....	8
<b>Mechanical Pulse</b>	
- Verifying MPT tools on Applications.....	10-11
- Reinstating MPT tools on Applications .....	12-13
- MPT Torque Graphs by Joint type.....	14-14
<b>AccuPulse</b>	
- AccuPulse setup.....	17
- Verifying AccuPulse on Applications.....	18-19
- Reinstating AccuPulse on Applications.....	20-21
- AccuPulse Torque Graphs by Joint type.....	22-23
<b>Precision Clutch Tool</b>	
- Verifying Clutch Tools on Applications.....	25-26
<b>Low Torque Clutch Tools</b>	
- Programming Instruction EY7411.....	27
Warranty and Service	
- Warranty and Service forms.....	28-29

**Best Practices!**

**Identifying Joint Types**

Types	Hard Joint Flush Point to Target Torque = <45°	Medium-Hard Joint Flush Point to Target Torque = >46° to <120°	Medium-Soft Joint Flush Point to Target Torque = >121° to <270°	Soft Joint Flush Point to Target Torque >270°
Example Joints	Examples: Metal to Metal Hard Slam	Examples: Hard Thin Gaskets Light Draw, P-Clamp, Multiple Washers, Electrical Connectors	Examples: Medium Thicker Gaskets Medium Draw, P-Clamp, Split Lock Washers	Examples: Soft Thicker Gaskets Long Draw, Hose Clamps, Rubber Washers, Dry Loctite
Description	Minimal resistance until the flush point then torque climbs at a steep rate.	Low resistance until the flush point then the torque climbs gradually.	Medium resistance with a gradual increase in torque.	High resistance throughout the fastening process.
Pictorial View				
Torque Curve Examples				
How The Joint Type Effects The Tool	Potentially higher torques than specified on the tool.	Specified torque range of the tool.	Lower torque capabilities than specified on the tool.	Potentially much lower torques than specified on the tool.

*(Angle declared by rotating the fastener from flush (50%) to target torque (100%))*

**Best  
Practices!**

## Remote Control Setup

### Programming the tool with the remote control

1. **Cycle Power** – Remove then re-install the battery on the tool.
2. **Enter Program Mode** – On the tool,
  - press and **hold down** the “**Light Button**” while pulling and releasing the tool’s “**Trigger/Switch**” you can then release both buttons.
  - The display starts blinking, the tool is now in program mode.
  - If the display is solid, return to step one.
3. **Edit Programmable Features** – While the display is flashing, use the remote control to change feature settings according to the charts on the next pages.

### Two-Way communication capable Tool Models:

EYFLA7AR, EYFLA8PR/CR/AR, EYFLA9PR/CR and EYFMA2PR/CR

(Please refer to the Owner's Manual for further instruction beyond Best Practices)

### These models can operate in both One-Way mode or Two-Way mode.

- One-Way communication mode –The Remote control is used to change tool settings.
- Two-Way communication mode – The Qualifier will change tool features and will override any settings made by the remote control.

**Each press of the A,B,C or D buttons on the remote control will cycle through the sub-menus.**

**The + and – buttons change the sub menu feature values**

**The blue button is the Save button. Press this button after features are selected to save changes.**



On the back is a quick reference for each of the buttons.

**Best Practices!**

## Mechanical Pulse

### EYFLA4 | EYFLA5 | EYFLA6 | EYFMA1 Quick Programming guide

Button	Number of Push	Setting Mode	Tool display	Description
<b>A</b>	0	Torque setting	1~30: Shut-off F: Non shut-off	Select stage with +/- button. Initial setting is 「F」
	1 time	Flush Detection Mode Setting	L1: Stage 1 L2: Stage 2	Select stage with +/- button. Initial setting is 「L1」 L1: For applications with no pulses before the flush point (fragile material) L2: For applications when the tool pulses before achieving flush point
<b>B</b>	1 times	Rehit Prevention	0~30 = OFF 1~3.0 = .1 tp 3.0 sec	Select stage with +/- button. Initial setting is 「0」
<b>C</b>	1 time	Restore Factory Defaults	F	All settings return to initial setting. On "F" press "Save" (Blue Button)
	2 times	Out Of Range/Anti-Theft	C0: OFF C1: ON	Select stage with +/- button. Initial setting is 「C0」 In the event that wireless communication cannot be completed between the tool and the qualifier, the tool will be disabled and cannot be operated.
<b>D</b>	1 time	Tool Model Number	Model Number	Will display model number

### EYFNA1 | EYFPA1 Quick Programming guide

Button	Number of Push	Setting Mode	Tool display	Description
<b>A</b>	0	Torque setting	1~30: Shut-off F: Non shut-off	Select stage with +/- button. Initial setting is 「F」
	1 time	Flush (Snug torque) detection mode setting	L1: Stage 1 L2: Stage 2	Select stage with +/- button. Initial setting is 「L1」 L1: For applications with no pulses before the flush point (fragile material) L2: For applications when the tool pulses before achieving flush point
	2 times	Buzzer setting	b0: No buzzer b1: Buzzer with OK b2: Buzzer with NOK	Select stage with +/- button. Initial setting is 「b0」
<b>B</b>	1 Times	LED Light	d1: by LED button (for d2: by trigger switch	Select stage with +/- button. Initial setting is 「d1」
	2 times	Rundown error detecting	0~30 = Off 1~3.0 = .1 to 3.0 sec	Select stage with +/- button. Initial setting is 「0」 If the clutch is activated before the programmable minimum runtime, the tool alerts the operator to a NOK fastening. (0.1sec. per stage)
	3 times	Variable speed control	P0: Variable speed (ON) P1: Single speed (OFF)	Select stage with +/- button. Initial setting is 「P0」 Speed can be controlled by use of the trigger.
<b>C</b>	1 time	Restore Factory Default	F	All settings return to initial setting. On "F" press the "Save" (Blue Button)
	2 times	Maintenance interval alarm	0~99 = Off 1-99 = 10,000-990,000 Run Downs	Select stage with +/- button. Initial setting is 「0」 When total fastening times are within 1 hour of preset maintenance interval, tool's display blinks notifying the operator. Once tool reaches the preset interval, the tool is looked out from further use.
	3 times	Out of range disable function	C0: OFF C1: ON	Select stage with +/- button. Initial setting is 「C0」 In the event that wireless communication cannot be completed between the tool and the qualifier, the tool will be disabled and cannot be operated.
<b>D</b>	1 time	Cross thread reduction	R0: OFF R1: 360°reverse (ON)	Select stage with +/- button. Initial setting is 「R0」 Tool first reverses 360 degree, aligning the threads, greatly reducing the possibility of cross threads.

**Best Practices!**

## AccuPulse

### EYFLA7 | EYFLA8 | EYFLA9 | EYFMA2 Quick Programming guide

Button	Number of Push	Setting Mode	Tool display	Description
<b>A</b>	0	Torque setting	1~40: Shut-off F: Non shut-off	Select stage with +/- button. Initial setting is 「F」.
	1 time	Flush (Snug torque) detection mode setting	L1: Stage1 ~L7: Stage7	Select stage with +/- button. Initial setting is 「L1」. L1: For applications with light load before snug point ~L7: For applications with heavy loads or varying joint rate before snug point
	2 times	Buzzer setting	b0: No buzzer b1: Buzzer with OK b2: Buzzer with NOK	Select stage with +/- button. Initial setting is 「b0」.
	3 times	Flush (Snug torque) detection delay	J0: OFF 01~30: 0.1~3.0sec.	Select stage with +/- button. Initial setting is 「J0」. The tool doesn't activate Snug Torque Detection mode and ignores load during rundown for a selected time period.
<b>B</b>	1 time	LED light	d1: by LED button (for 5min) d2: by trigger switch	Select stage with +/- button. Initial setting is 「d1」.
	2 times	Rundown error detecting	0~30: 0~3.0sec.	Select stage with +/- button. Initial setting is 「0」. If the clutch is activated before the programmable minimum runtime, the tool alerts the operator to a NOK fastening. (0.1sec. per stage)
	3 times	Variable speed control	P0: Variable speed (ON) P1: Single speed (OFF)	Select stage with +/- button. Initial setting is 「P0」. Speed can be controlled by use of the trigger.
<b>C</b>	1 time	Reset settings	F	All settings return to initial setting.
	2 times	Maintenance interval alarm	0~99: 0-99 Rundowns	Select stage with +/- button. Initial setting is 「0」 When total fastening times are within 1 hour of preset maintenance interval, tool's display blinks notifying the operator. Once tool reaches the preset interval, the tool is looked out from further use.
	3 times	Out of range disable function	C0: OFF C1: ON	Select stage with +/- button. Initial setting is 「C0」 In the event that wireless communication cannot be completed between the tool and the qualifier, the tool will be disabled and cannot be operated.
	4 times	Communication Mode	90: 1-way 91: 2-way	Only available on models equipped with 2-way communication Toggle communication mode between 1-way & 2-way
<b>D</b>	1 time	Cross thread reduction	R0: OFF R1: 360° reverse (ON)	Select stage with +/- button. Initial setting is 「R0」 Tool first reverses 360 degree, aligning the threads, greatly reducing the possibility of cross threads.
	2 times	Retightening prevention	U-U9: 0~3.0sec.	Select stage with +/- button. Initial setting is 「U」 Tool prevented from operating during a selected time period after shut-off.
	3 times	Socket extension mode	h0: Normal h1: for 150mm socket h2: for 250mm socket	Select stage with +/- button. Initial setting is 「h0」 RPM during impacts is adjusted depending on socket extension length to stabilize torque.

**Best Practices!**

## Clutch Tools

### EYFG1N | EYFG2N | EYFG3N Quick Programming guide

Button	Number of Push	Setting Mode	Tool display	Description
<b>A</b>	0	Speed Setting	80 = Full speed 15-80: 10 rpm each	Select stage with +/-button. Initial setting is 「80」 Adjustable speed in 10 rpm increments
	1 times	Buzzer setting	b0: No buzzer b1: Buzzer with OK b2: Buzzer with NOK	Select stage with +/-button. Initial setting is 「b0」
<b>B</b>	1 Times	LED Light	L1: by LED button (5min) L2: by trigger switch	Select stage with +/- button. Initial setting is 「L1」
	2 times	Rundown error detecting	0~30 = Off 1~3.0sec = .1 to 3.0sec	Select stage with +/-button. Initial setting is 「0」
	3 times	Variable speed control	P0: Variable speed (ON) P1: Single speed (OFF)	Select stage with +/-button. Initial setting is 「P0」 Speed can be controlled by use of the trigger.
<b>C</b>	1 time	Restore Factory Defaults	F	All settings return to initial setting. On "F" press "Save" (Blue Button)
	2 times	Maintenance interval alarm	0~99 = Off 1-99 = 10,000-990,000 Run Downs	Select stage with +/-button. Initial setting is 「0」 When total fastening times are within 1 hour of preset maintenance interval, tool's display blinks notifying the operator. Once tool reaches the preset interval, the tool is locked out from further use.
	3 times	Out of range disable function	C0: OFF C1: ON	Select stage with +/-button. Initial setting is 「C0」 In the event that wireless communication cannot be completed between the tool and the qualifier, the tool will be disabled and cannot be operated.
<b>D</b>	1 time	Cross thread reduction	R0: OFF R1: 360°reverse (ON)	Select stage with +/-button. Initial setting is 「R0」 Tool first reverses 360 degree, aligning the threads, greatly reducing the possibility of cross threads.
	2 times	Auto Down Shift	0~30 = Off 1~30 = .1 to 3.0sec	Select stage with +/-button. Initial setting is 「U」 High speed run down time starts on trigger pull then automatically downshifts to 300 rpm

\* *A clutch adjustment tool is required for torque settings.*

1. Rotate the clutch adjustment tool CW to open the tamper resistant door.
2. Flip the clutch adjustment tool over to adjust the clutch to the desired torque.
3. Rotating the clutch adjustment tool clockwise will increase torque and counter clockwise to decrease torque.
4. Once the desired torque is set, remember to close the tamper resistant door rotating the clutch adjustment tool CCW.

**Best Practices!**

<b>Setup Worksheet</b>		
<b>Production Floor Information</b>		
<b>Application</b>		
Application		Hood Install
Location		H26
Torque Units (Nm, Ft. Lbs., In. Lbs., Etc.)		Nm
Target Torque		20
Torque Tolerance (+/- %)		15%
Torque Tolerance (+/-)		3
Date of Install		2014-01-01
<b>Tool Info</b>		
Tool Model Number		EYFLA5A
Tool Serial Number		YLA5AR1212074
Flush Point (L1/L2)		L2
Tool Program Setting (1~30)		18
<b>Accessories</b>		
Brand of Sockets / Extensions / Etc.		Apex
Sockets / Extensions / Etc.		13mm w/ 10" Ext
<b>Residual Audit</b>		
Audit Wrench Make		Brand
Audit Wrench Model/Serial #		ABC/123
Audit Wrench Mode		Peak
Audit Wrench Settings		Torque/Angle/Threshold
Residual Audit Torque (Nm)		21
Calibration Date		2014-01-01
<b>Calibration Lab Information</b>		
<b>Calibration Unit Settings</b>		
Model #		EYFST22NM
Serial #		123456
Transducer Model #		EYFST22NM
Transducer Serial #		123456
Joint Simulator Model #		EYFJS22NM
Joint Type / Setting		Medium Hard
Mode		Pulse
Filter Frequency Setting (Hz)		500
Pulse Tool Compensation		1-800
Torque Units (Nm, Ft. Lbs., In. Lbs., Etc.)		Nm
Target Torque		20
Torque High Limit		23
Torque Low Limit		17
Flush Point (L1/L2)		L2
Tool Program Setting (1~30)		18
<b>Accessories</b>		
Brand of Sockets / Extensions / Etc.		Apex
Sockets / Extensions / Etc.		13mm
<b>Audit</b>		
Certification Results (Nm (+/- % or +/- Nm))		20 +/-20%



# Mechanical Pulse Tools

EYFLA4 | EYFLA5 | EYFLA6  
EYFMA1 | EYFNA1 | EYFPA1



**Best Practices!**

## Verify Mechanical Pulse Tools On Applications

Following these guidelines, including the “Set Up Worksheet”, will streamline the set up and verification process.



\*In most cases, Residual (Audit Wrench) & Dynamic (Transducer) torques will be different due to differences in the joint!



**Best Practices!**

## Reinstate Mechanical Pulse Tools On Applications

Following these guidelines, including the “Set Up Worksheet”, will streamline the set up and verification process.



\*In most cases, Residual (Audit Wrench) & Dynamic (Transducer) torques will be different due to differences in the joint!

**Best  
Practices!**

## Reinstate Panasonic Mechanical Pulse Tools On Applications

### 1. Look Up Application Setting On Worksheet

- **Worksheet** – Look up the application information on the “Panasonic Assembly Tool Set Up Worksheet”.

### 2. Set Up Tool

- **Obtain Tool & Attachments** – Obtain the tool, extensions and sockets for the application.
- **Program The Tool** – Referring to the worksheet, program the tool to the same settings as recorded previously confirming the Flush Point (L1/L2) & Program Setting (1-30)

### 3. Verify The Tool In The Calibration Lab – Update Worksheet

- **Set Up Transducer** – Set up the Analyzer/Software per the settings recorded in the worksheet.
- **Adjust Simulator** – Adjust the Joint Simulator per the recorded washer thickness in the worksheet.
- **Transducer** – Warm up the Joint Simulator and Tool before testing. Run 10 cycles on the joint simulator to get the components warmed up and grease moving.
- **Run The Tool** – Run the tool on the Transducer with the Joint Simulator.
  - Wait 10 seconds in between rundowns.


### 4. Run The Tool On The Application – Update Worksheet

- **Run The Tool** - Run the tool on the application and be sure to hold the trigger until the tool shuts off.
- **Audit The Fastener** - Conduct a static/residual audit of the fastener to verify accuracy.
- **Adjust Torque** - If the torque is out of specification, adjust the tool's Program Setting (1-30) to increase or decrease the torque until the residual audit is within specification.
  - If unable to achieve the required specifications, double check the tools set up (settings & attachments) for any inconsistencies.

### 5. Record / Tool History


- **Worksheet** – Update the worksheet with the above information if any changes were made to the tool, settings or attachments.

## Panasonic Assembly Tools Set Up Worksheet




## Hard Joint 30 Degrees

Approximate torque settings for various joint types  
 (Angle declared by rotating the fastener from flush (50%) to target torque (100%))



## Medium-Hard Joint 60 Degrees


Approximate torque settings for various joint types.  
 (Angle declared by rotating the fastener from flush (50%) to target torque (100%))



\*Tool set to L1


## Medium-Soft Joint 180 Degrees

Approximate torque settings for various joint types.  
 (Angle declared by rotating the fastener from flush (50%) to target torque (100%))



## Soft Joint >360 Degrees

Approximate torque settings for various joint types.  
 (Angle declared by rotating the fastener from flush (50%) to target torque (100%))



\*Tool set to L1

# AccuPulse


EYFLA7 | EYFLA8 | EYFLA9 | EYFMA2





# AccuPulse HR Setup Instructions

## Step 1 Select Tool & Initial Torque Setting




\*Chart based on medium/hard joint type

1. Choose correct tool & fastener size from chart
2. Set tool torque stage according to the chart & put tool in L1 mode.
3. Rundown fastener & audit with torque wrench
4. Adjust torque stage up or down to achieve target torque
5. If unable to achieve target torque proceed to step 2

## Step 2 Flush Detection Level Adjustment

1. Reset Torque Stage to initial setting from Step 1 #2
2. Adjust L mode from L1 to L2
3. Rundown Fastener & confirm Bolt head is Flush by VISUAL Check
4. If NOK increase L mode until Flush by Visual Check



5. If OK proceed to step 3

## Step 3 Set Final Torque Stage

1. Perform static audit on fastener with rotary transducer or torque wrench



2. Adjust target torque value until target torque is achieved

**☑ DONE!**

**Best Practices!**

## EYFLA7 | EYFLA8 | EYFLA9 | EYFMA2 Verify AccuPulse Tools On Applications

Following these guidelines, including the “Set Up Worksheet”, will streamline the set up and verification process.



\*In most cases, Residual (Audit Wrench) & Dynamic (Transducer) torques will be different due to differences in the joint!

**Best  
Practices!**

## Verify AccuPulse Tools On Applications

### 1. Application Specifications – Record to Worksheet

- **Specs** – Obtain the target torque, tolerance, extensions and sockets for the application.
- **Joint Type** – Determine the joint type (Hard 30°, Medium-Hard 60°, Medium-Soft 180°, Soft 360° (degrees are calculated by rotating the fastener from the flush point (snug torque) to final torque))
  - Dry Loctite, Lock Nuts, etc. will possibly cause a medium-soft or soft joint.

### 2. Determine The Tool – Record to Worksheet

- **Look Up The Tool** – Use the torque curve graphs to select the tool and be sure to use the joint type determined above.
- **Select Tool** – Locate the target torque on the left column; follow the line to the right to select the tool. Follow the chart directly down to obtain an estimated starting point to program the tool.
  - Suggestion – If more than one tool can be used in the torque range then consider using a larger tool on Medium-Soft/Soft joints and a smaller tool on Hard/Medium Hard joints.

### 3. Program The Tool Settings – Record to Worksheet

- **Flush Point Mode** – L1: For applications with light load before snug point  
L2~L7: For applications with heavy loads or varying joint rate before snug point.  
If the parts don't come together before target torque, increase the flush point.
- **Setting Torque** – Adjust the tools shut-off setting "**Program Setting**" (1~40) to the desired torque from the set up torque curves.

### 4. Run The Tool On The Application – Record to Worksheet

- **Run The Tool** - Run the tool on the application and be sure to hold the trigger until the tool shuts off.
- **Audit The Fastener** - Conduct a static/residual audit of the fastener to verify accuracy.
- **Adjust Torque** - If the torque is out of specification, adjust the tool's Program Setting (1-40) to increase or decrease the torque until the residual audit is within specification.
  - If unable to achieve the required specifications, consider using a larger tool on Medium-Soft/Soft joints and a smaller tool on Hard/Medium Hard joints.

### 5. Record / Tool History

- **Worksheet** – Document the above information on the "Panasonic Assembly Tool Set Up Worksheet".
- **Save Data** – Record the Tools Model, Program Setting, Flush Point (L1 –L7), Joint Type, Analyzer Settings, Sockets and Extensions.

### 6. Verify The Tool In The Calibration Lab – Record to Worksheet

- **Set Up Transducer** – Set up the Analyzer/Software per manufacturers suggested settings.
- **Adjust Simulator** – Adjust the Joint Simulator per the transducer quick start guide.
- **Transducer** – Warm up the Joint Simulator and Tool before testing. Run 10 cycles on the joint simulator to get the components warmed up and grease moving.
- **Run The Tool** – Run the tool on the Transducer with the Joint Simulator.
  - Wait 5 seconds in between rundowns.

### 7. Record / Tool History

- **Worksheet** – Document the above information on the "Panasonic Assembly Tool Set Up Worksheet".
- **Save Data** – Record the Tools Model, Program Setting, Flush Point (L1-L7), Joint Type, Analyzer Settings, Sockets and Extensions.

**Best Practices!**

## Reinstate AccuPulse Tools On Applications

Following these guidelines, including the “Set Up Worksheet”, will streamline the set up and verification process.



\*In most cases, Residual (Audit Wrench) & Dynamic (Transducer) torques will be different due to differences in the joint!

**Best  
Practices!**

## Reinstate Panasonic AccuPulse Tools On Applications

### 1. Look Up Application Setting On Worksheet

- **Worksheet** – Look up the application information on the “Panasonic Assembly Tool Set Up Worksheet”.

### 2. Set Up Tool

- **Obtain Tool & Attachments** – Obtain the tool, extensions and sockets for the application.
- **Program The Tool** – Referring to the worksheet, program the tool to the same settings as recorded previously confirming the Flush Point (L1-L7) & Program Setting (1-40)

### 3. Verify The Tool In The Calibration Lab – Update Worksheet

- **Set Up Transducer** – Set up the Analyzer/Software per the settings recorded in the worksheet.
- **Adjust Simulator** – Adjust the Joint Simulator per the recorded washer thickness in the worksheet.
- **Transducer** – Warm up the Joint Simulator and Tool before testing. Run 10 cycles on the joint simulator to get the components warmed up and grease moving.
- **Run The Tool** – Run the tool on the Transducer with the Joint Simulator.
  - Wait 10 seconds in between rundowns.


### 4. Run The Tool On The Application – Update Worksheet

- **Run The Tool** - Run the tool on the application and be sure to hold the trigger until the tool shuts off.
- **Audit The Fastener** - Conduct a static/residual audit of the fastener to verify accuracy.
- **Adjust Torque** - If the torque is out of specification, adjust the tool's Program Setting (1-40) to increase or decrease the torque until the residual audit is within specification.
  - If unable to achieve the required specifications, double check the tools set up (settings & attachments) for any inconsistencies.

### 5. Record / Tool History


- **Worksheet** – Update the worksheet with the above information if any changes were made to the tool, settings or attachments.

## Panasonic Assembly Tools Set Up Worksheet




## Hard Joint 30 Degrees

Approximate torque settings for various joint types  
Angle declared by rotating the fastener from flush (50%) to target torque (100%)  
Tool set to L1




## Medium Hard Joint 60 Degrees

Approximate torque settings for various joint types  
Angle declared by rotating the fastener from flush (50%) to target torque (100%)  
Tool set to L1




### Medium Soft Joint 180 Degrees

Approximate torque settings for various joint types  
Angle declared by rotating the fastener from flush (50%) to target torque (100%)  
Tool set to L1



### Soft Joint > 360 Degrees

Approximate torque settings for various joint types  
Angle declared by rotating the fastener from flush (50%) to target torque (100%)  
Tool set to L1



# Clutch Tools

EYFGA1 | EYFGA2 | EYFGA3  
EYFGB1 | EYFGB2 | EYFGB3





**Best Practices!**

**EYFGA1 | EYFGA2 | EYFGA3  
EYFGB1 | EYFGB2 | EYFGB3  
Verify Panasonic Clutch Tools On Applications**

Following these guidelines, including the “Set Up Worksheet”, will streamline the set up and verification process.



\*In most cases, Residual (Audit Wrench) & Dynamic (Transducer) torques will be different due to differences in the joint!

**Best  
Practices!**

## Verify Panasonic Clutch Tools On Applications

### 1. Application Specifications – Record to Worksheet

- **Specs** – Obtain the target torque, tolerance, extensions and socket/bit for the application.

### 2. Set Up Tool – Update Worksheet

- **Adjust The Torque** – Use the clutch adjustment tool to increase (cw) or decrease (ccw) the output torque.
- **Program The Tool** – Program the tools speed to meet the application and enable additional quick features if necessary.

### 3. Verify The Tool In The Calibration Lab – Update Worksheet

- **Set Up Transducer** – Set up the Analyzer/Software per the settings recorded in the worksheet.
- **Adjust Simulator** – Adjust the Joint Simulator to the joint type recorded in the worksheet.
- **Transducer** – Warm up the Joint Simulator and Tool before testing. Run 10 cycles on the joint simulator to get the components warmed up and grease moving.
- **Run The Tool** – Run the tool on the Transducer with the Joint Simulator.


### 4. & 5. Run The Tool On The Application – Update Worksheet

- **Run The Tool** - Run the tool on the application and be sure to hold the trigger until the tool shuts off.
- **Audit The Fastener** - Conduct a residual audit of the fastener to verify accuracy.
- **Adjust Torque** - If the torque is out of specification, adjust the tools clutch to increase or decrease the torque until the residual audit is within specification.

### 6. Record / Tool History

- **Worksheet** – Update the worksheet with the above information if any changes were made to the tool, settings or attachments.

## Panasonic Assembly Tools Set Up Worksheet



### Adjusting The Clutch

*No tools are required.*

1. Rotate the clutch handle to adjust the clutch to the desired torque.
2. Rotating the clutch adjustment tool clockwise will increase torque and counter clockwise to decrease torque.


### Programming a EY7411 Clutch Tool

*Panasonic remote control is not required.*

1. **Enable Programming Mode** – Slide the “**Hold Switch**” up to enable program mode and press the forward/reverse switch to illuminate the control panel. The count display lamp and “Up” or “Down” are illuminated.
2. **Edit Count Function** – Press “**Mode**” while the control panel is illuminated.
  - a. **Screw Count Setting** – Set the number of screws with “+” or “-“. The range can be set within 0-99, 0 is not counted.
  - b. **Count System Up or Down** – Press the “**Mode**” button to change the direction of counting screws. “+” (Up) or “-“ (Down).
3. **Edit Buzzer Function** – Press “**Mode**” for 2 or more seconds while the control panel is illuminated. Count “**F1**” should be displayed. Press the “+” or “-“ to change the buzzer sounds.  
(b0=No Sound (Off) / b1=Low Pitched Sound / b2=Medium Pitched Sound / b3=High Pitched Sound)
4. **Edit Rehit Function** – Press “**Mode**” for 2 or more seconds while the control panel is illuminated. Count “**F1**” should be displayed. Press the “**Mode**” button again to illuminate “**F2**”. Press the “+” or “-“ to change the time.  
(0=Off / 1=0.1 Seconds / 30=3 Seconds)
5. **Save & Exit** – Slide the “**Hold Switch**” down to exit programming mode.

#### Reference for Adjusting Torque

Setting	Torque	Use
1	Approx: 0.29 N·m (3.0 kgf-cm or 2.6 in-lbs)	For driving screws
5	Approx: 0.82 N·m (8.4 kgf-cm or 7.3 in-lbs)	
9	Approx: 1.35 N·m (13.8 kgf-cm or 12.0 in-lbs)	
13	Approx: 1.88 N·m (19.2 kgf-cm or 16.6 in-lbs)	
17	Approx: 2.41 N·m (24.6 kgf-cm or 21.3 in-lbs)	
21	Approx: 2.94 N·m (30.0 kgf-cm or 26.0 in-lbs)	For powerful driving screws and drilling
	Approx: 4.4 N·m (45.0 kgf-cm or 39.0 in-lbs)	



# Panasonic Assembly Tools

## Panasonic Factory Service Center

4900 George McVay Drive Suite B  
McAllen, Texas 78503

February 16, 2018

Dear Panasonic Assembly Tool Client:

As part of our continuing effort to provide the best service in the industry, you can now send your Panasonic Assembly Tools to our repair facility in McAllen, Texas.

When you send your tool in for service, it will be repaired by factory trained technicians with original Panasonic parts. Your assembly tool will be cleaned, lubricated, and returned to original factory specifications. This program covers the following models:

**Warranty terms are 1-year from DOP on parts and labor.  
Repaired items are covered for 90 days.**

To take advantage of this service offering, please fill out the form and send your tool to:

**Panasonic Factory Service Center  
Attn: Assembly Tool Repair  
4900 George McVay Drive  
Suite B  
McAllen, TX 78503  
Tel: 866-907-9111 or Direct: 956-683-2930  
Email: [panacare@us.panasonic.com](mailto:panacare@us.panasonic.com)**

To provide prompt service, please include a copy of the original Proof-of-Purchase or invoice noting the date of purchase of your Panasonic Assembly Tool. To assist our technicians in troubleshooting, please include a brief description of the problem or issue your power tool is experiencing.

For Out-of-Warranty service, the rate is: \$49.65 + the cost of parts + return shipping.

We look forward to providing your Panasonic Assembly Tool service needs.

Sincerely,

Panasonic Assembly Tool Team

# Repair Equipment Worksheet

Point of Contact  Panasonic  
 Distributor / Rep  
 Customer

Today's Date \_\_\_\_\_  
 Date Rec'd \_\_\_\_\_  
 Rec'd By \_\_\_\_\_

## Distibutor / Rep Information Customer Information

Dist / Rep Name \_\_\_\_\_  
 Company Name / Address \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 Email Address \_\_\_\_\_  
 Phone # \_\_\_\_\_  
 Return To Dist/ Rep   
 **Do Not Require Signature For Return Shipment**

Customer Name \_\_\_\_\_  
 Company Name / Address \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 Email Address \_\_\_\_\_  
 Phone # \_\_\_\_\_  
 Return To Customer

## Tool Information Order Information

Please check mark the box below if included in shipment and  
 please keep your Charger, Remote and Controller Power Cable (Unless Needing Repaired)

Tool Model # \_\_\_\_\_  
 Tool Serial # \_\_\_\_\_  
 Battery Serial # \_\_\_\_\_  
 Controller Model # \_\_\_\_\_  
 Controller Serial # \_\_\_\_\_  
 Other \_\_\_\_\_  
 \_\_\_\_\_

Warranty only - please include a copy of the PO with the date of purchase.

Panasonic Invoice # \_\_\_\_\_  
 Distributor / Customer PO # \_\_\_\_\_

## Shipping / Warranty

Urgency of Repair  Exception  High  Normal  
(UPS RED) (No Backups)

Warranty  Yes  No

Estimate To Be Given  Yes  No

Estimate Approved By \_\_\_\_\_  
 Estimate Approval Date \_\_\_\_\_

Issue or Problem \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

Comments \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

## Returning Product Information

Date Returned \_\_\_\_\_  
 Shipped Via \_\_\_\_\_

\* In efforts to help reduce costs and speed up turn around time for repairs, we require a \$100.00 pre-approval.  
 In addition, any tools not repaired will have a \$25.00 diagnostic fee and the choice to return the tool or dispose the tool at Panasonic.